


Shared FLOOD wiring for RapidChange ATC and FrancisCreation AutoDustBoot

* Both devices SHARE the FLOOD function:
The AutoDustBoot uses it to raise and lower the boot
The ATC magazine uses it to open and close the cover.



Sienci SLB-EXT Connector Legend